

MGC 4-pot alloy brake kit with EBC discs



FITTING INSTRUCTIONS

Frontline's 4-pot brake conversion is a direct replacement for the original standard brakes.

It fits inside the standard 15" wire and steel wheels and the alloy conversions

- Support the car on axle stands or similar. Ensure that the hand brake is securely applied. Remove the front wheels.
- Disconnect the brake hoses (or remove the hoses if replacing).
- Remove the brake calipers.
NOTE: We recommend that you check the condition of the wheel bearings and replace if necessary. See workshop manual.
- Remove the hubs and discs.
- Remove the discs from the hubs and fit the new ones. Clean the hubs to ensure that there is no rust or debris to prevent the correct seating of the disc on the hub.
- Refit the hub and disc assembly to the car. Adjust the wheel bearings in accordance with the workshop manual.
- The new calipers come pre assembled with special mounting brackets. *NOTE: These should not be disassembled from the calipers.*

- Fit the new calipers to the stub axles using the original bolts and the new locking tabs supplied. When the bolts are tight, secure the new locking tabs supplied against the bolt heads with a blunt chisel and small hammer.
 - Fit the new banjos and bolts to the calipers. The banjo has a bend in it to clear the caliper. The banjo should be fitted with the bend away from the caliper and pointing almost vertically and slightly in towards the centre of the wheel. Fit the two copper washers supplied per banjo and bolt, one on either side of the banjo, but do not fully tighten the banjo bolt at this stage.
 - Fit the brake hose to the banjo. Initially nip the fittings up and check carefully that the hose does not become strained or trapped on the suspension or the wheel when on full lock both ways and with the suspension raised and lowered.
 - Securely tighten the banjo bolt to the calliper and then the hose to the banjo.
 - Fit the brake pads and ensure that the anti rattle springs and the locking clips are in the locating pins. The pins come preassembled.
 - Bleed the brakes, please NOTE the new calliper have 2 bleed screws per calliper, both require bleeding; start with the outer one first then repeat for the inner one. Repeat on the other calliper
- NOTE:** Do NOT change to a synthetic fluid or vice versa unless you are changing your entire brake system. Remember to top up the fluid after bleeding the brakes. We recommend that you flush your entire brake fluid through if it has not been changed recently. If you are commonly using a conventional mineral brake fluid, we recommend a DOT 4.1 or Dot 5.1 mineral brake fluid.*
- Pump the pedal a few times after bleeding the brakes and while holding the brakes under pressure, check for any fluid leaks.
 - De grease the disc if required prior to driving
 - Refit the wheels.

Testing your brakes: *Do this with care*

- The brake pads require bedding in and will not perform efficiently straight away. Follow normal bedding in procedure.
- After initial testing check that all the fittings are tight and that there is no fluid leak.

Take a little time to get used to your new brakes and enjoy!



FRONTLINE DEVELOPMENTS
 9 STATION YARD, STEVENTON, ABINGDON-ON-THAMES, OX13 6RX
 PHONE 01235 832632 ♦ FAX 01235 833122
 EMAIL info@frontlinedevelopments.com
 WEBSITE <http://www.frontlinedevelopments.com>
 Frontline Developments is a trading name of Frontline Spridget Ltd
 REGISTERED No 3043576

